


=====
BIOS PARAMETER BLOCK (BPB)
=====

BPB: 512 BYTES / SECTOR
 2 SECTOR / BLOCK
 1 RESERVED SECTOR (BOOT)
 2 FAT - STRUCTURES
 128 DIRECTORY - ENTRIES
 1600 SECTORS / DISK
 0F9H MEDIA ID / FAT ID
 3 SECTORS / FAT

 20 SECTORS / CYLINDERS


 NO LOGICAL SKEW



=====

DRIVER CONSTRUCTION

=====



BREAK -->
 ADDRESS

 SPR HEADER <-----|

.....

 280 DEVICE HEADER

.....

 280 SPR-FILE PICTURE

.....

=====

DEVICE DRIVER HEADER FORMAT

=====

<p>DWORD Pointer to next Device (Set to -1,-1 on installable devices)</p>
<p>WORD Attributes Bit 15 = 1 if char device or ^{Zeichengröße} 0 if block device if bit 15 is 1: Bit 0 = 1 if Current ^{Standard input} sti device Bit 1 = 1 if Current sto device Bit 2 = 1 if Current NUL device Bit 3 = 1 if Current CLOCK dev. Bit 4 = 1 if Special device bit 14 is the IOCTL bit bit 13 is NON IBM Format Bit</p>
<p>WORD Pointer to Device STRATEGY Entry Point</p>
<p>WORD Pointer to Device INTERRUPT Entry Point</p>
<p>8 BYTE Character Device Name Field Left Justified Space Filled Upper Case Characters</p> <p>For Block Devices, first byte is Number of Units Defined</p>

Note that the device entry points are words. They must be offsets from the same segment number used to point to this table. I.e. if XXX:YYY points to the start of this table, then XXX:STRATEGY and XXX:INTERRUPT are the entry points.

DISPATCH TABLE DEFINITION


DISPTAB ----->	REQUEST PACKET OFFSET (WORD)
	REQUEST PACKET SEGMENT (WORD)
	RESERVED (WORD)
	RESERVED (WORD)
	FUNCTION 0 (INIT) . HANDLER OFFSET (WORD)
	FUNCTION 1 (MEDIA CHECK) " " "
	...
	...
	FUNCTION 12 (IOCTL OUTPUT) HANDLER OFFSET (WORD)

- 0 INIT
- 1 MEDIA CHECK (Block only, NOP for character)
- 2 BUILD BPB - " -
- 3 IOCTL INPUT (Only called if device has IOCTL)
- 4 INPUT (Read)
- 5 NON-DESTRUCTIVE INPUT NO WAIT (Char devices only)
- 6 INPUT STATUS - " -
- 7 INPUT FLUSH - " -
- 8 OUTPUT (write)
- 9 OUTPUT (write) with verify
- 10 OUTPUT STATUS - " -
- 11 OUTPUT FLUSH - " -
- 12 IOCTL OUTPUT (Only called if device has IOCTL)

=====

280 DEVICE HEADER

=====



=====
CALL OF DISPATCH TABLE FUNCTIONS
=====

FAR CALL with

Parameters:

CL	UNIT NUMBER
ES:DI	POINTER TO REQUEST HEADER TAIL (REQ. HEADER ADDR. + 13)
DS	DEVICE HANDLER CS

RESULT

AX	STATUS WORD
----	-------------

=====

MS-DOS KERNEL

=====

INT 29

STRATEGY CALL:

call: PUSH SI
MOV SI, OFFSET DISPTAB
INT 29

INT 30

INTERRUPT CALL:

call: PUSH SI
MOV SI, OFFSET DISPTAB
INT 30

INT 31

call: ON CALL DL

DL= Function No.

0: DOWNLOAD

ES:SI = Pointer to SPR-File

~~CX = New device ID~~

Result

AL = ERRCODE

1: ACTIVATE

CX = device ID

AL = ERRCODE

2:-7: MESSAGE I/O

8: RESOLVE A REQUEST

DS = Data segment (=CS I.A.)


```
=====
MS-DOS IO-KERNEL (DEFINITION OF THE SYSTEM FUNCTIONS)
=====
```

System interrupts definitions

```
STRATEGY          INT 29
INTERRUPT          INT 30
SYSFUNC           INT 31
```

Dispatch table constants

```
DTAB              BUF    8  Dispatch table buffer size
```

System function numbers definitions

```
DOWNLOAD          SF     0  Z80 SPR-File download function
                   ON CALL: SI = POINTER (OFFSET) TO THE SPR-
                           HEADER
                           ES = POINTER (SEGMENT) TO THE SPR-
                           HEADER
                   RETURNS: AL = ERROR CODE, 000H = NO ERROR
-----
ACTIVATE          SF     1  Z80 Device handler activation
                   ON CALL: CX = DEVICE IDENTIFIER
                   RETURNS: AL = ERROR CODE, 000H = NO ERROR
-----
BYTEMSGSEND      SF     2  Byte message send function
                   ON CALL: AL = BYTE MESSAGE
-----
BYTEMSGRECV     SF     3  Byte message recive function
                   RETURNS: AL = BYTE MESSAGE
-----
WORDMSGSEND     SF     4  Word message send function
                   ON CALL: CX = WORD MESSAGE
-----
WORDMSGRECV     SF     5  Word message recive function
                   RETURNS: BX = WORD MESSAGE
-----
STRMSGSEND      SF     6  String message send function
                   ON CALL: CX = STRING MESSAGE LENGTH
                           SI = POINTER (OFFSET) TO STRING
                           MESSAGE
                           ES = POINTER (SEGMENT) TO STRING
                           MESSAGE
```

STRMSGRECV SF 7 String message receive function

ON CALL: CX = STRING MESSAGE LENGTH
 DI = POINTER (OFFSET) TO STRING
 MESSAGE
 ES = POINTER (SEGMENT) TO STRING
 MESSAGE

RESOLVEREQ SF 8 Resolve transfer request function

ON CALL: CL = UNIT NUMBER
 SI = DATEA ITEM LENGTH
 DI = REQUEST PACKET PTR. OFF. (+13)
 ES = REQUEST PACKET PTR. SEG.
 BX = ACCES HANDLER PTR. OFF.
 DS = ACCES HANDLER PTR. SEG.

RETURNS: AX = MS-DOS ERROR STATUS

MULTIBYTE/
 MULTISECTOR
 TRANSFERS

e.g. : READ ONE SECTOR FROM DISK:

ON CALL: BX = BLOCK NUMBER
 CL = DRIVE NUMBER
 DX = SECTOR LENGTH
 DI = SECTOR PTR. SEGMENT
 ES = SECTOR PTR. OFFSET

RETURNS: AX = MODIFIED ERROR CODE *


READONE PROC FAR
 .
 .
 .
 RET
 READONE ENP

*) MODIFIED ERROR CODE: SAME AS STANDARD ERROR CODE BUT
 WITHOUT BUSY/DONE - BITS
 (ALWAYS ZERO)


=====

REQUEST PACKET HEADER

=====



STATUS WORD



The status word ist zero on entry and is always set by the driver interrupt routine on return.

Bit 8 is the done bit, it means the operation is complete. For the moment the Driver just sets it to one when it exits, in the future this will be set by an asynchronous interrupt routine to tell the DOS the operation is complete.

=====

EXTENDED SCREEN FUNCTIONS

=====

ANSI ESCAPE SEQUENCES

\bar{A} $\hat{=}$ Escape ~~the~~

This section explains how the ANSI escape sequences are defined for MS-DOS. An ANSI escape sequence is a series of characters (beginning with an escape character or keystroke) that you can use to define functions to DOS. Specifically, you can use ANSI escape sequences from within your program to control the movement of the cursor on the screen. You can also reassign key functions and change graphics functions. Examples on how to use ANSI escape sequences are included at the end of this section.

Notes:

1. The default value (1) is used when no explicit value or a value of zero is specified.
2. n represents "numeric parameter". This is a decimal number specified with ASCII digits.
3. Use hex 1B to represent ESC.
4. Use hex 5B to represent \bar{A} ([)

CURSOR FUCTIONS

The following escape sequences affect the cursor position on the screen.

ANSI Stand. 111

CUP - Cursor Position

ESC [n;nH
↳ Decimal

also links 1,1

HVP - Horizontal & Vertical Position

ESC [n;nf

CUP and HVP move the cursor to the screen positio indicated by the n parameters. The first parameter specifies the line number, and the second parameter specifies the column number.

EXTENDED SCREEN AND KEYBOARD FUNCTIONS

The default value is 1. When no parameters are specified, the cursor is moved to the home position.

CUU - Cursor Up

ESC [nA

This sequence moves the cursor up one line without changing columns. The value of n determines the number of lines moved. The default value for n is one. The CUU sequence is ignored if the cursor is already on the top line.

CUD - Cursor Down

ESC [nB

This sequence moves the cursor down one line without changing columns. The value of n determines the number of lines moved. The default value for n is 1. The CUD sequence is ignored if the cursor is already on the bottom line.

CUF - Cursor Forward

ESC [nC

The CUF sequence moves the cursor forward one column without changing lines. The value of n determines the number of columns moved. The default value for n is 1. The CUF sequence is ignored if the cursor is already in the far right column.

CUB - Cursor Backward

ESC [nD

This escape sequence moves the cursor back one column without changing lines. The value of n determines the number of columns moved. The default value for n is 1. The CUB sequence is ignored if the cursor is already in the far left column.

DSR - Device Status Report *

ESC [dn

The console driver will output a CPR sequence (see below) on receipt of the DSR escape sequence.

CPR - Cursor Position Report (from console driver to system) *

ESC [n;nR

The CPR sequence reports current cursor position via standard input. The first parameter specifies the current line and the second parameter specifies the current column.

SCP - Save Cursor Position

ESC [s

The current cursor position is saved. This cursor position can be restored with the RCP sequence (see below).

RCP - Restore Cursor Position

ESC [u

This sequence restores the cursor position to the value it had when the console driver receives the SCP sequence.

* not yet available

ERASING

The following escape sequences affect erase functions.

ED - Erase Display

ESC [2J

The ED sequence erases the screen, and the cursor goes to the home position.

EL - Erase Line

ESC [K

This sequence erases from the cursor to the end of the line (including the cursor position)

MODES OF OPERATION

The following escape sequences affect screen graphics.

SGR - Set Graphics Rendition

ESC [n;...;nm

The SGR escape sequence invokes the graphic functions specified by the parameter(s) describes below. The graphic functions remain until the next occurrence of an SGR escape sequence.

Parameter	Parameter Function
0	All Attributes Off
7	Reverse Video On

SM - Set Mode

ESC [=nh
or ESC [=7h
or ESC [?7h

The SM escape sequence changes the screen type to one of the following parameter:

Parameter	Function
7	wraparound at end of line

ADDITION SM5

ESC [>5h Cursor Invisible

RM - Reset Mode

ESC [=n1
or ESC [=71
or ESC [?71

Parameter 7 will reset the wrap at the end of line mode (characters that extend past the end of the line are lost).

ADDITION RM5

ESC [>51 Flashing Cursor

CURSOR MODE CM

ESC [3;nz

Parameter	Function
0	Flashing Rectangle
1	Standing Rectangle
2	Flashing Rectangle
3	Standing Rectangle
4	Invisible Cursor

SCROLL MODE

ESC [nw

^ 1 A A O W

Parameter	Function
1	Soft Scroll On
0	Soft Scroll Off