

APPENDIX C

LISTS OF ESCAPE SEQUENCES  
TRANSMITTED BY TM31

Sequence	Key
Esc J Q	Alt
Esc O A	cnar attr
Esc O B	undo
Esc O C	windo
Esc J D	print
Esc O E	c-tab, c-s-tab
Esc J F	num pad s-U
Esc J G	s-tab
Esc O H	num pad c-U
Esc O I	c-slt
Esc J J	c-return
Esc O K	s-slt
Esc J L	s-ins
Esc J M	c-ins
Esc O N	s-alt
Esc J O	c-alt
Esc O P	F1
Esc O Q	F2
Esc O R	F3
Esc O S	F4
Esc O T	F5
Esc O U	F6
Esc O V	F7
Esc O W	F8
Esc O X	F9
Esc O Y	reset
Esc J Z	move
Esc O L	copy
Esc O \	help
Esc O J	home
Esc O ^	cmd plain
Esc O _	c-accept
Esc J `	c-F1 and c-num.pad 1
Esc O a	c-F2 and c-num.pad 2
Esc O b	c-F3 and c-num.pad 3
Esc J c	c-F4
Esc J d	c-F5 and c-num.pad 5
Esc O e	c-F6
Esc O f	c-F7 and c-num.pad 7
Esc O g	c-F8 and c-num.pad 8
Esc O h	c-F9 and c-num.pad 9
Esc O i	num pad s-4
Esc O j	s-5 5
Esc O k	s-7 7
Esc J l	c-cmd
Esc O m	c-home
Esc O n	c-help
Esc O o	s-num.pad 0

Sequence	Key
Esc O p	s-F1 and s-num.pad 1
Esc O q	s-F2 and s-num.pad 2
Esc O r	s-F3 and s-num.pad 3
Esc O s	s-F4
Esc O t	s-F5 and c-move
Esc O u	s-F6
Esc O v	s-F7 and c-copy
Esc O w	s-F8 and s-num.pad 3
Esc O x	s-Fx and s-num.pad y
Esc O y	s-reset
Esc O z	s-move
Esc O [	s-copy
Esc O	s-cmd
Esc O }	s-home
Esc O ~	s-help
Esc L 2 I	Slct
Esc L 2 H	c-erase
Esc L 2 O	num pad s-
Esc L 2 Q	num pad s -
Esc L 2 R	num pad c -
Esc L 2 U	s-char attr
Esc L 2 V	s-windo
Esc L 2 D	c-down arrow
Esc L 2 C	c-right arrow
Esc L 2 G	s up arrow
Esc L 2 H	s-down arrow
Esc L 2 I	s-right arrow
Esc L 2 J	s-left arrow
Esc L 2 L	cdelete
Esc L 2 N	s-delete
Esc L 2 O	c-delete
Esc L 2 P	s-exit
Esc L 2 r	ins
Esc L 2 s	c-undo
Esc L 2 t	c-print
Esc L 2 u	c-char
Esc L 2 v	c-windo
Esc L 2 w	erase
Esc L 2 x	s-erase
Esc L 2 y	num pad c-
Esc L 2 z	s-undo
Esc L 2 [	s-print
Esc L 2	c up arrow
Esc L 2 }	c-left arrow
Esc L A	up arrow
Esc L B	down arrow
Esc L C	right arrow
Esc L D	left arrow

\*\*\*\*\* International characters GERMAN (deut) keyboard \*\*\*\*\*

Sequence	Language	Character
Esc N 40h 5 b H	GERMAN	..A
Esc N 41h 5 c H	GERMAN	..O
Esc N 42h 5 d H	GERMAN	..U
Esc N 43h 7 b H	GERMAN	..n
Esc N 44h 7 c H	GERMAN	..o
Esc N 45h 7 d H	GERMAN	..u
Esc N 46h 7 e H	GERMAN	Beta
Esc N 47h	GERMAN	a grave
Esc N 48h	GERMAN	e grave
Esc N 49h	GERMAN	u grave
Esc N 4Ah	GERMAN	e acute
Esc N 4Bh	GERMAN	a circumflex
Esc N 4Ch	GERMAN	e circumflex
Esc N 4Dh	GERMAN	c circle
Esc N 4Eh	GERMAN	o circumflex
Esc N 4Fh	GERMAN	up arrow
Esc N 54h	GERMAN	r circle
Esc N 70h	GERMAN	1/4
Esc N 6Dh	GERMAN	division operator
Esc N 50h	GERMAN	left arrow
Esc N 51h	GERMAN	down arrow
Esc N 53h	GERMAN	pound sign
Esc N 6Ah	GERMAN	paragraph mark
Esc N 6Ch	GERMAN	section mark
Esc N 7Ah	GERMAN	1/2
Esc N 5Fh	GERMAN	vertical bar